



YFM35FAS YFM350FAS

5UH2-AE1

SUPPLEMENTARY SERVICE MANUAL

FOREWORD

This Supplementary Service Manual has been prepared to introduce new service and data for the YFM35FAS/YFM350FAS. For complete service information procedures it is necessary to use this Supplementary Service Manual together with the following manual.

YFM4FAR/YFM400FAR SERVICE MANUAL: 5TE2-AE1

**YFM35FAS/YFM350FAS
SUPPLEMENTARY
SERVICE MANUAL
©2003 by Yamaha Motor Co., Ltd.
First edition, July 2003
All rights reserved.
Any reproduction or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.**

NOTICE

This manual was produced by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on Yamaha machine has a basic understanding of the mechanical ideas and the procedures of machine repair. Repairs attempted by anyone without this knowledge are likely to render the machine unsafe and unfit for use.

Yamaha Motor Company, Ltd. is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

NOTE: _____
Designs and specifications are subject to change without notice.

IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the machine operator, a bystander or a person inspecting or repairing the machine.



A CAUTION indicates special precautions that must be taken to avoid damage to the machine.

NOTE: A NOTE provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

MANUAL ORGANIZATION

This manual consists of chapters for the main categories of subjects. (See "Illustrated symbols")

1st title ①: This is the title of the chapter with its symbol in the upper right corner of each page.

2nd title ②: This title indicates the section of the chapter and only appears on the first page of each section. It is located in the upper left corner of the page.

3rd title ③: This title indicates a sub-section that is followed by step-by-step procedures accompanied by corresponding illustrations.

EXPLODED DIAGRAMS

To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.

1. An easy-to-see exploded diagram ④ is provided for removal and disassembly jobs.
2. Numbers ⑤ are given in the order of the jobs in the exploded diagram. A number that is enclosed by a circle indicates a disassembly step.
3. An explanation of jobs and notes is presented in an easy-to-read way by the use of symbol marks ⑥. The meanings of the symbol marks are given on the next page.
4. A job instruction chart ⑦ accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
5. For jobs requiring more information, the step-by-step format supplements ⑧ are given in addition to the exploded diagram and the job instruction chart.

② CLUTCH ① ENG

CLUTCH

Order	Job name/Part name	Q'ty	Remarks
Removing the clutch			
Primary and secondary sheaves			
1	Cover	1	Remove the parts in the order below. Refer to "PRIMARY AND SECONDARY SHEAVES".
2	Clutch housing assembly	1	
3	Gasket/dowel pin	1/2	
4	One-way clutch bearing	1	
5	Nut	1	
6	Clutch carrier assembly	1	
For installation, reverse the removal procedure.			

③ CLUTCH ENG

REMOVING THE CLUTCH

1. Remove:

- Clutch housing assembly
- Gasket
- Dowel pins

NOTE:
Working in crisscross pattern, loosen each bolt 1/4 of a turn. Remove them after all of them are loosened.

2. Straighten:

- Punched portion of the nut ①.

3. Remove:

- Nut ①

NOTE:
Use a clutch holding tool ② to hold the clutch carrier assembly.

Clutch holding tool:
P/N. YM-91042, 90890-04086

CHECKING THE CLUTCH

1. Check:

- Clutch housing ①
Heat damage/wear/damage → Replace.
- One-way clutch bearing ②
Chafing/wear/damage → Replace.

NOTE:

- Replace the one-way clutch assembly and clutch housing as a set.
- The one-way clutch bearing ② must be installed with the arrow mark side facing up.

.....

Checking steps:

- Install the one-way clutch bearing and clutch carrier assembly to the clutch housing and hold the clutch carrier assembly.
- When turning the clutch carrier assembly clockwise the clutch carrier assembly should turn freely. If not, the one-way clutch assembly is faulty. Replace it.
- When turning the clutch carrier assembly counterclockwise the clutch housing and clutch carrier assembly should be engaged. If not, the one-way clutch assembly is faulty. Replace it.

.....

























4 - 51

4 - 53

ILLUSTRATED SYMBOLS

Illustrated symbols ① to ⑩ are printed on the top right of each page and indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Engine
- ⑤ Cooling system
- ⑥ Carburetion
- ⑦ Drive train
- ⑧ Chassis
- ⑨ Electrical
- ⑩ Troubleshooting

① GEN INFO 	② SPEC 	
③ CHK ADJ 	④ ENG 	
⑤ COOL 	⑥ CARB 	
⑦ DRIV 	⑧ CHAS 	
⑨ ELEC 	⑩ TRBL SHTG ?	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	
⑰ 	⑱ 	
⑲ 	⑳ 	㉑ 
㉒ 	㉓ 	㉔ 
㉕ 	㉖ New	

Illustrated symbols ⑪ to ⑱ are used to identify the specifications appearing in the text.

- ⑪ Can be serviced with engine mounted
- ⑫ Filling fluid
- ⑬ Lubricant
- ⑭ Special tool
- ⑮ Torque
- ⑯ Wear limit, clearance
- ⑰ Engine speed
- ⑱ Ω , V, A

Illustrated symbols ⑲ to ㉔ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑲ Apply engine oil
- ⑳ Apply gear oil
- ㉑ Apply molybdenum disulfide oil
- ㉒ Apply wheel bearing grease
- ㉓ Apply lithium-soap-based grease
- ㉔ Apply molybdenum disulfide grease

Illustrated symbols ㉕ to ㉖ in the exploded diagrams indicate where to apply a locking agent ㉕ and when to install a new part ㉖.

- ㉕ Apply the locking agent (LOCTITE®)
- ㉖ Replace

CONTENTS

GENERAL INFORMATION

SPECIAL TOOLS	1
---------------------	---

SPECIFICATIONS

GENERAL SPECIFICATIONS	2
MAINTENANCE SPECIFICATIONS	5
ENGINE	5
CHASSIS	15
ELECTRICAL	19
LUBRICATION POINTS AND LUBRICANT TYPES	21
ENGINE	21
OIL FLOW DIAGRAMS	22
CABLE ROUTING	26

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION	34
PERIODIC MAINTENANCE/LUBRICATION	34
SEAT, CARRIERS, FENDERS AND FUEL TANK	36
SEAT, FRONT CARRIER, FRONT BUMPER AND FRONT FENDER	36
FUEL TANK	38
ENGINE	39
CHECKING THE OIL TEMPERATURE WARNING LIGHT	39

ENGINE

CYLINDER HEAD	40
CAMSHAFT, ROCKER ARMS AND VALVES	42
CYLINDER AND PISTON	44
RECOIL STARTER AND A.C. MAGNETO	45
BALANCER GEARS AND OIL PUMP	47
OIL PUMP	49
REMOVING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR	50
REMOVING THE BALANCER DRIVE GEAR AND BUFFER BOSS	50
CHECKING THE OIL PUMP DRIVEN GEAR	50
CHECKING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR	50
INSTALLING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR	51

OIL COOLER	52
PRIMARY AND SECONDARY SHEAVES	54
PRIMARY SLIDING SHEAVE	56
SECONDARY SHEAVE	57
ASSEMBLING THE PRIMARY SHEAVE	58
ASSEMBLING THE SECONDARY SHEAVE	58
CLUTCH	60
CRANKCASE	62
STARTER MOTOR, TIMING CHAIN AND OIL FILTER	62
CRANKCASE	64
CRANKCASE BEARINGS	65
SEPARATING THE CRANKCASE	66
ASSEMBLING THE CRANKCASE	66
CRANKSHAFT	68
REMOVING THE CRANKSHAFT	69
INSTALLING THE CRANKSHAFT	69
TRANSMISSION	70
INSTALLING THE TRANSMISSION	71
MIDDLE GEAR	72
MIDDLE DRIVE SHAFT	72
MIDDLE DRIVEN SHAFT	73
SELECTING THE MIDDLE DRIVE AND DRIVEN GEAR SHIMS	75

DRIVE TRAIN

FRONT CONSTANT VELOCITY JOINTS AND DIFFERENTIAL GEAR	79
MEASURING AND ADJUSTING THE DIFFERENTIAL GEAR LASH	81

CHASSIS

REAR BRAKE	83
CHECKING THE REAR BRAKE	85
INSTALLING THE REAR BRAKE	86
STEERING SYSTEM	89
STEERING STEM	89
FRONT ARMS AND FRONT SHOCK ABSORBERS	91

ELECTRICAL

ELECTRIC STARTING SYSTEM	93
STARTER MOTOR	93
ASSEMBLING THE STARTER MOTOR	94
SIGNAL SYSTEM	95
CIRCUIT DIAGRAM	95
COOLING SYSTEM	99
CIRCUIT DIAGRAM	99
TROUBLESHOOTING	100

TROUBLESHOOTING

FAULTY GEAR SHIFTING	104
HARD SHIFTING	104
SHIFT LEVER DOES NOT MOVE	104
JUMPS OUT OF GEAR	104
OVERHEATING	104
OVERHEATING	104
FAULTY BRAKE	105
POOR BRAKING EFFECT	105

YFM35FAS/YFM350FAS WIRING DIAGRAM

GENERAL INFORMATION

EB102001

SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools may differ by shape and part number from country to country. In such a case, two types are provided.





When placing an order, refer to the list provided below to avoid any mistakes.

For US and CDN

P/N. YM-, YU-, YS-, YK-, ACC-

Except for US and CDN



P/N. 90890-

Tool No.	Tool name/How to use	Illustration
Pot 90890-01274 Bolt 90890-01275	Crankshaft installer pot Crankshaft installer bolt These tools are used to install the crankshaft.	
90890-01309	Spacer This tool is used to install the crankshaft.	
Adapter 90890-01383 YM-1383 Spacer 90890-04081 YM-91044	Adapter Spacer (crankshaft installer) These tools are used to install the crankshaft.	
YU-90050	Crankshaft installer set These tools are used to install the crankshaft.	



SPECIFICATIONS

GENERAL SPECIFICATIONS

Item	Standard
Model code:	5UH2 (for CDN) 5UH4 (for Europe) 5UH5 (for Oceania)
Dimensions:	
Overall length	1,984 mm (78.1 in)
Overall width	1,085 mm (42.7 in)
Overall height	1,120 mm (44.1 in)
Seat height	827 mm (32.6 in)
Wheelbase	1,233 mm (48.5 in)
Minimum ground clearance	245 mm (9.7 in)
Minimum turning radius	3,000 mm (118.1 in)
Basic weight:	
With oil and full fuel tank	258 kg (569 lb)
Engine:	
Engine type	Air-cooled 4-stroke, SOHC
Cylinder arrangement	Forward-inclined single cylinder
Displacement	348 cm ³
Bore × stroke	83.0 × 64.5 mm (3.27 × 2.54 in)
Compression ratio	9.2 : 1
Standard compression pressure (at sea level)	1,050 kPa (10.5 kg/cm ² , 149.3 psi) at 750 r/min
Starting system	Electric and recoil starter
Lubrication system:	Wet sump
Oil type or grade:	
Engine oil	
For CDN	
	
For Europe, Oceania	
	
Final gear oil	SAE 80API "GL-4" Hypoid Gear Oil
Differential gear oil	SAE 80API "GL-4" Hypoid Gear Oil
	API service SE, SF, SG type or higher



Item	Standard
Oil capacity: Engine oil Periodic oil change With oil filter replacement Total amount Final gear case oil Periodic oil change Total amount Differential gear case oil Periodic oil change Total amount	 2.2 L (1.94 Imp qt, 2.33 US qt) 2.3 L (2.02 Imp qt, 2.43 US qt) 3.1 L (2.73 Imp qt, 3.28 US qt) 0.23 L (0.20 Imp qt, 0.24 US qt) 0.25 L (0.22 Imp qt, 0.26 US qt) 0.35 L (0.31 Imp qt, 0.37 US qt) 0.40 L (0.35 Imp qt, 0.42 US qt)
Air filter:	Wet type element
Fuel: Type Fuel tank capacity Fuel reserve amount	Regular unleaded gasoline only (for CDN, Europe) Unleaded gasoline only (for Oceania) 13.5 L (2.97 Imp gal, 3.57 US gal) 3.3 L (0.73 Imp gal, 0.87 US gal)
Carburetor: Type/quantity Manufacturer	BSR33/1 MIKUNI
Spark plug: Type/manufacturer Spark plug gap	DR8EA/NGK 0.6 ~ 0.7 mm (0.024 ~ 0.028 in)
Clutch type:	Wet, centrifugal automatic
Transmission: Primary reduction system Secondary reduction system Secondary reduction ratio Transmission type Operation Single speed automatic Sub transmission ratio Reverse gear	V-belt Shaft drive 41/21 × 24/18 × 33/9 (9.545) V-belt automatic Left hand operation 2.60 ~ 0.75 : 1 35/20 (1.750) 26/15 (1.733)
Chassis: Frame type Caster angle Camber angle Kingpin angle Kingpin offset Trail Tread (STD) front rear Toe-in	Steel tube frame 4° 1° 11° -5.0 mm (-0.20 in) 21 mm (0.83 in) 850 mm (33.46 in) 825 mm (32.48 in) 0 ~ 10 mm (0 ~ 0.39 in)

GENERAL SPECIFICATIONS




SPEC







Item	Standard
Tires:	
Type	Tubeless
Size	front AT25 × 8–12
	rear AT25 × 10–12
Manufacturer	front MAXXIS (for CDN, Europe) CHENG SHIN (for Oceania)
	rear MAXXIS (for CDN, Europe) CHENG SHIN (for Oceania)
Type	front M911Y (for CDN, Europe) C828 (for Oceania)
	rear M912Y (for CDN, Europe) C828 (for Oceania)
Tire pressure (cold tire):	
Maximum load*	210 kg (463 lb)
Off-road riding	front 22 ~ 28 kPa (0.22 ~ 0.28 kg/cm ² , 3.2 ~ 4.0 psi)
	rear 22 ~ 28 kPa (0.22 ~ 0.28 kg/cm ² , 3.2 ~ 4.0 psi)
*Load in total weight of rider accessories	
Brakes:	
Front brake	type Dual disc brake
	operation Right hand operation
Rear brake	type Drum brake
	operation Left hand and right foot operation
Suspension:	
Front suspension	Double wishbone
Rear suspension	Swingarm (monocross)
Shock absorbers:	
Front shock absorber	Coil spring/oil damper
Rear shock absorber	Coil spring/oil damper
Wheel travel:	
Front wheel travel	160 mm (6.30 in)
Rear wheel travel	180 mm (7.09 in)
Electrical:	
Ignition system	D.C. C.D.I.
Generator system	A.C. magneto
Battery type	YTX14AH
Battery capacity	12 V 12 Ah
Headlight type:	
Krypton bulb	
Bulb wattage × quantity:	
Headlight	12 V 30 W/30 W × 2
Tail/brake light	12 V 5 W/21 W × 1
Meter light	14 V 3 W × 1
Indicator lights	
Neutral	12 V 1.7 W × 1
Reverse	12 V 1.7 W × 1
Oil temperature	12 V 1.7 W × 1
Four-wheel drive	14 V 1.7 W × 1



**MAINTENANCE SPECIFICATIONS
ENGINE**

Item	Standard	Limit
Cylinder head: Warp limit * 	----	0.03 mm (0.0012 in)
Cylinder: Bore size Taper limit Out of round limit	82.970 ~ 83.020 mm (3.2665 ~ 3.2685 in) ---- ----	83.100 mm (3.2720 in) 0.05 mm (0.0016 in) 0.01 mm (0.0004 in)
Camshaft: Drive method Cam dimensions  Intake Exhaust Camshaft runout limit 	Chain drive (left) ---- "A" 40.62 ~ 40.72 mm (1.5992 ~ 1.6031 in) "B" 32.18 ~ 32.28 mm (1.2669 ~ 1.2709 in) "A" 40.62 ~ 40.72 mm (1.5992 ~ 1.6031 in) "B" 32.18 ~ 32.28 mm (1.2669 ~ 1.2709 in) ----	---- 40.52 mm (1.5953 in) 32.08 mm (1.2630 in) 40.52 mm (1.5953 in) 32.08 mm (1.2630 in) 0.03 mm (0.0012 in)





Item	Standard	Limit	
Cam chain:			
Cam chain type/No. of links	92RH2005/110	----	
Cam chain adjustment method	Automatic	----	
Rocker arm/rocker arm shaft:			
Rocker arm inside diameter	11.980 ~ 11.998 mm (0.4717 ~ 0.4724 in)	12.058 mm (0.4747 in)	
Rocker arm shaft outside diameter	11.961 ~ 11.971 mm (0.4709 ~ 0.4713 in)	11.931 mm (0.4697 in)	
Rocker-arm-to-rocker-arm-shaft clearance	0.009 ~ 0.037 mm (0.0004 ~ 0.0015 in)	0.080 mm (0.0031 in)	
Valves, valve seats, valve guides:			
Valve clearance (cold)	IN 0.06 ~ 0.10 mm (0.0024 ~ 0.0039 in)	----	
	EX 0.16 ~ 0.20 mm (0.0063 ~ 0.0079 in)	----	
Valve dimensions			
			
Head Diameter	Face Width	Seat Width	Margin Thickness
"A" head diameter	IN	39.9 ~ 40.1 mm (1.5709 ~ 1.5787 in)	----
	EX	33.9 ~ 34.1 mm (1.3346 ~ 1.3425 in)	----
"B" face width	IN	2.26 mm (0.0890 in)	----
	EX	2.26 mm (0.0890 in)	----
"C" seat width	IN	1.2 ~ 1.4 mm (0.0472 ~ 0.0551 in)	1.6 mm (0.0630 in)
	EX	1.2 ~ 1.4 mm (0.0472 ~ 0.0551 in)	1.6 mm (0.0630 in)
"D" margin thickness	IN	1.0 ~ 1.4 mm (0.0394 ~ 0.0551 in)	----
	EX	0.8 ~ 1.2 mm (0.0315 ~ 0.0472 in)	----
Stem outside diameter	IN	6.975 ~ 6.990 mm (0.2746 ~ 0.2752 in)	6.950 mm (0.2736 in)
	EX	6.955 ~ 6.970 mm (0.2738 ~ 0.2744 in)	6.915 mm (0.2722 in)
Guide inside diameter	IN	7.000 ~ 7.012 mm (0.2756 ~ 0.2761 in)	7.03 mm (0.2768 in)
	EX	7.000 ~ 7.012 mm (0.2756 ~ 0.2761 in)	7.03 mm (0.2768 in)
Stem-to-guide clearance	IN	0.010 ~ 0.037 mm (0.0004 ~ 0.0015 in)	0.080 mm (0.0031 in)
	EX	0.030 ~ 0.057 mm (0.0012 ~ 0.0022 in)	0.100 mm (0.0039 in)

MAINTENANCE SPECIFICATIONS

SPEC







Item		Standard	Limit
Stem runout limit		----	0.01 mm (0.0004 in)
			
	Valve seat width	IN	1.2 ~ 1.4 mm (0.0472 ~ 0.0551 in)
	EX	1.2 ~ 1.4 mm (0.0472 ~ 0.0551 in)	----
Valve spring:			
Inner spring			
Free length	IN	39.9 mm (1.57 in)	37.9 mm (1.49 in)
	EX	39.9 mm (1.57 in)	37.9 mm (1.49 in)
Set length (valve closed)	IN	33.6 mm (1.32 in)	----
	EX	33.6 mm (1.32 in)	----
Compressed pressure (installed)	IN	104.9 ~ 120.6 N (10.7 ~ 12.3 kg, 23.58 ~ 27.11 lb)	----
	EX	104.9 ~ 120.6 N (10.7 ~ 12.3 kg, 23.58 ~ 27.11 lb)	----
Tilt limit *	IN		2.5°/1.7 mm (2.5°/0.07 in)
	EX		2.5°/1.7 mm (2.5°/0.07 in)
			
	Direction of winding (top view)	IN	Counterclockwise
	EX	Counterclockwise	----



Item		Standard	Limit	
Outer spring	Free length	IN	43.27 mm (1.70 in)	41.27 mm (1.62 in)
		EX	43.27 mm (1.70 in)	41.27 mm (1.62 in)
	Set length (valve closed)	IN	36.6 mm (1.44 in)	----
		EX	36.6 mm (1.44 in)	----
	Compressed pressure (installed)	IN	235.4 ~ 251.1 N (24.0 ~ 25.6 kg, 52.92 ~ 56.45 lb)	----
		EX	235.4 ~ 251.1 N (24.0 ~ 25.6 kg, 52.92 ~ 56.45 lb)	----
	Tilt limit *	IN	----	2.5°/1.9 mm (2.5°/0.07 in)
		EX	----	2.5°/1.9 mm (2.5°/0.07 in)
	Direction of winding (top view)	IN	Clockwise	----
		EX	Clockwise	----
<p>Piston:</p>				
Piston to cylinder clearance		0.040 ~ 0.060 mm (0.0016 ~ 0.0024 in)	0.150 mm (0.0059 in)	
Piston size "D"		82.920 ~ 82.970 mm (3.2646 ~ 3.2665 in)	----	
Measuring point "H"		5 mm (0.20 in)	----	
Piston offset		0.5 mm (0.0200 in)	----	
Offset direction		Intake side	----	
Piston pin bore inside diameter		19.004 ~ 19.015 mm (0.7482 ~ 0.7486 in)	19.045 mm (0.7498 in)	
Piston pin outside diameter		18.991 ~ 19.000 mm (0.7477 ~ 0.7480 in)	18.971 mm (0.7469 in)	



Item	Standard	Limit
<p>Piston rings:</p> <p>Top ring</p>  <p>Type</p> <p>Dimensions (B × T)</p> <p>End gap (installed)</p> <p>Side clearance (installed)</p> <p>2nd ring</p>  <p>Type</p> <p>Dimensions (B × T)</p> <p>End gap (installed)</p> <p>Side clearance</p> <p>Oil ring</p>  <p>Dimensions (B × T)</p> <p>End gap (installed)</p>	<p>Barrel</p> <p>1.2 × 3.3 mm (0.05 × 0.13 in)</p> <p>0.20 ~ 0.40 mm (0.008 ~ 0.016 in)</p> <p>0.03 ~ 0.08 mm (0.0012 ~ 0.0032 in)</p> <p>Taper</p> <p>1.5 × 3.4 mm (0.06 × 0.13 in)</p> <p>0.20 ~ 0.40 mm (0.008 ~ 0.016 in)</p> <p>0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in)</p> <p>2.8 × 2.8 mm (0.11 × 0.11 in)</p> <p>0.3 ~ 0.9 mm (0.01 ~ 0.04 in)</p>	<p>----</p> <p>----</p> <p>0.65 mm (0.0256 in)</p> <p>0.13 mm (0.0051 in)</p> <p>----</p> <p>----</p> <p>0.75 mm (0.0295 in)</p> <p>0.13 mm (0.0051 in)</p> <p>----</p> <p>----</p>
<p>Crankshaft:</p>  <p>Crank width "A"</p> <p>Runout limit C1</p> <p>C2</p> <p>Big end side clearance "B"</p> <p>Big end radial clearance "E"</p>	<p>58.95 ~ 59.00 mm (2.321 ~ 2.323 in)</p> <p>----</p> <p>----</p> <p>0.35 ~ 0.85 mm (0.0138 ~ 0.0335 in)</p> <p>0.004 ~ 0.023 mm (0.0002 ~ 0.0009 in)</p>	<p>----</p> <p>0.03 mm (0.0012 in)</p> <p>0.03 mm (0.0012 in)</p> <p>1.0 mm (0.04 in)</p> <p>----</p>

MAINTENANCE SPECIFICATIONS


SPEC


Item	Standard	Limit
Balancer:		
Balancer drive method	Gear	----
Automatic centrifugal clutch:		
Clutch shoe thickness	1.5 mm (0.06 in)	1.0 mm (0.04 in)
Clutch-in revolution	1,950 ~ 2,350 r/min	----
Clutch-stall revolution	3,350 ~ 3,850 r/min	----
Transmission:		
Main axle deflection limit	----	0.08 mm (0.0031 in)
Drive axle deflection limit	----	0.08 mm (0.0031 in)
Shifter:		
Shifter type	Shift cam and guide bar	----
Air filter oil grade:	Engine oil	----
Carburetor:		
I. D. mark	5UH1 00	----
Main jet (M.J)	#130	----
Main air jet (M.A.J)	#70	----
Jet needle (J.N)	5ETY1-2	----
Needle jet (N.J)	P-2M	----
Pilot air jet (P.A.J.1)	#80	----
Pilot air jet (P.A.J.2)	1.3	----
Pilot outlet (P.O)	0.8	----
Pilot jet (P.J)	#17.5	----
Bypass 1 (B.P.1)	0.8	----
Bypass 2 (B.P.2)	0.8	----
Bypass 3 (B.P.3)	0.8	----
Pilot screw (P.S)	1-1/2 turns out	----
Valve seat size (V.S)	2.0	----
Starter jet (G.S.1)	57.5	----
Starter jet (G.S.2)	0.9	----
Throttle valve size (Th.V)	100	----
Float height (F.H)	13.0 mm (0.51 in)	----
Fuel level (F.L)	4.0 ~ 5.0 mm (0.16 ~ 0.20 in)	----
Engine idle speed	1,450 ~ 1,550 r/min	----
Intake vacuum	32 kPa (240 mmHg, 9.4 inHg)	----




Item	Standard	Limit
Oil pump:		
Oil filter type	Foam	----
Oil pump type	Trochoid	----
Tip clearance	0.15 mm (0.006 in)	0.20 mm (0.008 in)
Side clearance	0.04 ~ 0.09 mm (0.002 ~ 0.004 in)	----
Bypass valve setting pressure	78 ~ 118 kPa (0.78 ~ 1.18 kg/cm ² , 11.3 ~ 17.1 psi)	----
Oil pressure (hot)	20 kPa (0.20 kg/cm ² , 2.9 psi) at 1,500 r/min	----
Pressure check location	Cylinder head	----
Shaft drive:		
Middle gear backlash	0.1 ~ 0.3 mm (0.004 ~ 0.012 in)	----
Final gear backlash	0.1 ~ 0.2 mm (0.004 ~ 0.008 in)	----
Differential gear backlash	0.05 ~ 0.25 mm (0.0020 ~ 0.0098 in)	----

Lubrication chart:







Item	Standard	Limit
<p>Cylinder head tightening sequence:</p> 		



Tightening torques

Part to be tightened	Part name	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m·kg	ft·lb	
Cylinder head (exhaust pipe)	Stud bolt	M6	2	7	0.7	5.1	
Cylinder head	Bolt	M10	4	32	3.2	23	
	Bolt	M8	2	20	2.0	14	
Camshaft bearing retainer	Bolt	M6	2	8	0.8	5.8	
Spark plug	—	M12	1	18	1.8	13	
Oil gallery bolt	Bolt	M6	1	7	0.7	5.1	
Cylinder	Bolt	M6	1	10	1.0	7.2	
Starter pulley	Bolt	M10	1	55	5.5	40	
Balancer driven gear	Nut	M16	1	60	6.0	43	
Valve adjusting screw	Nut	M7	2	20	2.0	14	
Tappet cover (intake)	Bolt	M6	2	10	1.0	7.2	
Tappet cover (exhaust)	Bolt	M6	3	10	1.0	7.2	
Camshaft sprocket	Bolt	M10	1	60	6.0	43	
Camshaft sprocket cover	Bolt	M6	2	10	1.0	7.2	
Timing chain tensioner cap	Bolt	M11	1	23	2.3	17	
Timing chain tensioner	Bolt	M6	2	11	1.1	8.0	
Timing chain guide (intake)	Bolt	M6	2	10	1.0	7.2	
Oil strainer	Bolt	M5	2	4	0.4	2.9	
Oil filter union bolt	—	M20	1	68	6.8	49	
Oil filter cartridge	—	M20	1	17	1.7	12	
Oil cooler	Bolt	M6	4	7	0.7	5.1	
Oil cooler fan	Bolt	M6	3	6	0.6	4.3	
Oil hose union bolt	—	M14	2	50	5.0	36	
Oil hose (oil cooler side)	—	M16	2	21	2.1	15	
Oil hose (crankcase side)	—	M16	2	35	3.5	25	
Oil pump assembly	Bolt	M6	3	7	0.7	5.1	
Oil pump housing	Screw	M5	1	5	0.5	3.6	
Plate (oil pump driven gear)	Bolt	M6	2	7	0.7	5.1	
Intake manifold	Bolt	M8	2	20	2.0	14	
Crankcase	Bolt	M8	3	20	2.0	14	
	Bolt	M6	15	10	1.0	7.2	
Oil drain bolt	Bolt	M12	1	23	2.3	17	
Bearing retainer (right crankcase)	Bolt	M6	2	10	1.0	7.2	
Bearing retainer (left crankcase)	Torx screw	M6	1	11	1.1	8.0	
Crankcase oil passage plug	—	M14	1	25	2.5	18	
Lead holder (stator assembly)	Bolt	M5	2	7	0.7	5.1	
Drive belt case	Bolt	M6	9	10	1.0	7.2	
Bearing housing (primary sheave)	Bolt	M6	4	10	1.0	7.2	
Drive belt case cover	Bolt	M6	14	10	1.0	7.2	
Crankcase cover	Bolt	M6	12	10	1.0	7.2	
Stator assembly	Screw	M6	3	7	0.7	5.1	

MAINTENANCE SPECIFICATIONS

SPEC



Part to be tightened	Part name	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m·kg	ft·lb	
Pickup coil	Bolt	M5	2	7	0.7	5.1	
Starter one-way clutch	Bolt	M8	3	30	3.0	22	
Recoil starter	Bolt	M6	4	10	1.0	7.2	
Clutch carrier assembly	Nut	M22	1	140	14.0	100	Stake.
Clutch housing assembly	Bolt	M6	8	10	1.0	7.2	
Middle drive shaft bearing retainer	Torx screw	M8	4	25	2.5	18	
Middle drive shaft drive pinion gear	Nut	M22	1	130	13.0	94	Stake.
Middle drive shaft bearing housing	Bolt	M8	4	32	3.2	23	
Middle driven pinion gear bearing retainer	Nut	M65	1	110	11.0	80	 Left-handed threads
Universal joint yoke (middle driven pinion gear)	Nut	M14	1	97	9.7	70	
Middle driven pinion gear bearing housing	Bolt	M8	4	25	2.5	18	
Middle driven shaft bearing retainer	Nut	M55	1	80	8.0	58	 Left-handed threads
Primary sliding sheave cap	Screw	M4	3	3	0.3	2.2	
Primary sliding sheave assembly	Nut	M16	1	100	10.0	72	
Secondary sheave assembly	Nut	M16	1	100	10.0	72	
Secondary sheave spring retainer	Nut	M36	1	90	9.0	65	
Shift shaft stopper bolt	—	M14	1	18	1.8	13	
Shift lever assembly	Bolt	M6	1	14	1.4	10	
Neutral switch	—	M10	1	17	1.7	12	
Reverse switch	—	M10	1	17	1.7	12	
Thermo unit	—	M12	1	20	2.0	14	
Muffler and exhaust pipe	Bolt	M8	2	15	1.5	11	
Exhaust pipe	Nut	M6	2	12	1.2	8.7	
Muffler	Bolt	M10	2	25	2.5	18	
Exhaust pipe bracket (exhaust pipe)	Bolt	M6	2	14	1.4	10	
Exhaust pipe bracket (engine)	Bolt	M6	2	10	1.0	7.2	
Starter motor	Bolt	M6	2	10	1.0	7.2	
Speedometer gear unit	Bolt	M6	2	10	1.0	7.2	
	Screw	M6	2	7	0.7	5.1	






CHASSIS

Item	Standard	Limit
Steering system: Steering bearing type	Ball and race bearing	----
Front suspension: Shock absorber travel	99 mm (3.90 in)	----
Spring free length	265 mm (10.43 in)	----
Spring fitting length	231.9 mm (9.13 in)	----
Spring rate (K1)	13.5 N/mm (1.35 kg/mm, 75.60 lb/in)	----
Stroke (K1)	0 ~ 99 mm (0 ~ 3.90 in)	----
Optional spring	No	----
Rear suspension: Shock absorber travel	126 mm (4.96 in)	----
Spring free length	317 mm (12.48 in)	----
Spring fitting length	283.1 mm (11.15 in)	----
Spring rate (K1)	27.4 N/mm (2.74 kg/mm, 153.43 lb/in)	----
Stroke (K1)	0 ~ 126 mm (0 ~ 4.96 in)	----
Optional spring	No	----
Swingarm: Free play limit		
end	----	1 mm (0.04 in)
side	----	1 mm (0.04 in)
Front wheel: Type	Panel wheel	----
Rim size	12 × 6.0 AT	----
Rim material	Steel	----
Rim runout limit		
radial	----	2 mm (0.08 in)
lateral	----	2 mm (0.08 in)
Rear wheel: Type	Panel wheel	----
Rim size	12 × 7.5 AT	----
Rim material	Steel	----
Rim runout limit		
radial	----	2 mm (0.08 in)
lateral	----	2 mm (0.08 in)



Tightening torques

Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m·kg	ft·lb	
Engine bracket (front-upper) and frame	M8	33	3.3	24	
Engine bracket (front-lower) and frame	M8	33	3.3	24	
Engine bracket (front-upper) and engine	M10	42	4.2	30	
Engine bracket (front-lower) and engine	M10	42	4.2	30	
Engine and frame (rear-upper)	M10	56	5.6	40	
Engine and frame (rear-lower)	M10	56	5.6	40	
Frame and bearing retainer (steering stem holder bearing)	M42	40	4.0	29	
Select lever assembly and frame	M8	23	2.3	17	
Swingarm	M12	82	8.2	59	
Rear shock absorber and frame	M12	82	8.2	59	
Final gear case and swingarm	M10	63	6.3	45	
Final gear case and rear axle housing	M10	63	6.3	45	
Swingarm and rear axle housing	M12	63	6.3	45	
Differential gear case and frame	M10	55	5.5	40	
Front arm and frame	M10	45	4.5	32	
Front shock absorber and frame	M10	45	4.5	32	
Front shock absorber and upper front arm	M10	45	4.5	32	
Steering stem, pitman arm and frame	M14	190	19.0	140	
Steering stem holder and frame	M8	23	2.3	17	Use lock washer
Steering stem and handlebar holder	M8	23	2.3	17	
Pitman arm and tie-rod end	M12	30	3.0	22	
Tie-rod and locknut	M12	40	4.0	29	
Steering knuckle and upper front arm	M12	30	3.0	22	
Steering knuckle and lower front arm	M12	30	3.0	22	
Steering knuckle and tie-rod	M12	30	3.0	22	
Fuel tank and fuel cock	M6	4	0.4	2.9	
Fuel tank	M6	10	1.0	7.2	
Front wheel and wheel hub	M10	55	5.5	40	
Front axle and wheel hub	M16	150	15.0	110	
Steering knuckle and brake caliper	M8	30	3.0	22	
Front brake disc and wheel hub	M8	30	3.0	22	
Rear wheel and rear wheel hub	M10	55	5.5	40	
Rear axle and nut	M16	150	15.0	110	
Brake drum cover and brake shoe plate	M6	7	0.7	5.1	
Front brake hose and steering knuckle	M6	7	0.7	5.1	
Front brake hose and upper front arm	M6	7	0.7	5.1	
Front brake hose and frame	M6	7	0.7	5.1	
Front brake pipe nut	M10	19	1.9	13	
Front brake hose union bolt	M10	27	2.7	19	
Bleed screw	M8	6	0.6	4.3	

MAINTENANCE SPECIFICATIONS

SPEC



Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m·kg	ft·lb	
Master cylinder and handlebar	M6	7	0.7	5.1	
Footrest bracket and frame	M8	16	1.6	11	
Front bumper and frame	M8	34	3.4	24	
Front carrier and frame	M8	34	3.4	24	
Front carrier and front bumper	M8	34	3.4	24	
Rear carrier and frame	M8	34	3.4	24	
Engine skid plate	M6	7	0.7	5.1	
Differential gear oil filler bolt	M14	23	2.3	17	
Differential gear oil drain bolt	M10	10	1.0	7.2	
Differential gear case and bearing housing	M8	25	2.5	18	
Gear motor	M8	13	1.3	9.4	
Final gear oil filler bolt	M14	23	2.3	17	
Final gear oil drain bolt	M14	23	2.3	17	
Bearing retainer (drive pinion gear)	M65	100	10.0	72	
Final gear case and bearing housing	M10	40	4.0	29	
	M8	23	2.3	17	
Battery holding bracket	M6	7	0.7	5.1	
Footrest board and footrest bracket	M6	7	0.7	5.1	
Trailer hitch bracket	M10	32	3.2	23	
Front brake pad holding bolt	M8	17	1.7	12	
Front brake caliper retaining bolt	M8	17	1.7	12	
Rear brake light switch bracket	M8	23	2.3	17	
Rear brake light switch cover	M6	7	0.7	5.1	
Rear brake lever holder bracket	M6	7	0.7	5.1	
Brake camshaft lever	M6	9	0.9	6.5	
Oil hose protector	M6	7	0.7	5.1	



ELECTRICAL

Item	Standard	Limit
Voltage:	12 V	----
Ignition system:		
Ignition timing (B.T.D.C.)	10°/ 1,500 r/min	----
Advancer type	Digital	----
C.D.I.:		
Magneto model/manufacturer	F4T475/MITSUBISHI	----
Pickup coil resistance/color	459 ~ 561 Ω at 20 °C (68 °F)/ White/Red – White/Green	----
Rotor rotation direction sensing coil resistance/color	0.086 ~ 0.105 Ω at 20 °C (68 °F)/ Red – White/Blue	----
C.D.I. unit model/manufacturer	F8T40371/MITSUBISHI	----
Ignition coil:		
Model/manufacturer	2JN/YAMAHA	----
Minimum spark gap	6 mm (0.24 in)	----
Primary winding resistance	0.18 ~ 0.28 Ω at 20 °C (68 °F)	----
Secondary winding resistance	6.32 ~ 9.48 kΩ at 20 °C (68 °F)	----
Spark plug cap:		
Type	Resin	----
Resistance	10 kΩ	----
Charging system:		
Type	A.C. magneto generator	----
Model/manufacturer	F4T475/MITSUBISHI	----
Nominal output	14 V 18 A at 5,000 r/min	----
Charging coil resistance/color	0.49 ~ 0.62 Ω at 20 °C (68 °F)/ White – White	----
Rectifier/regulator:		
Regulator type	Semi conductor-short circuit	----
No-load regulated voltage (DC)	14.1 ~ 14.9 V	----
Model/manufacturer	SH640E-11/SHINDENGEN	----
Capacity	14 A	----
Withstand voltage	200 V	----
Battery:		
Specific gravity	1.32	----
Electric starter system:		
Type	Constant mesh	----
Starter motor		
Model/manufacturer	SM-13/MITSUBA	----
Output	0.7 kW	----
Armature coil resistance	0.0015 ~ 0.0025 Ω at 20 °C (68 °F)	----

MAINTENANCE SPECIFICATIONS

SPEC



Item	Standard	Limit
Brush overall length	12.0 mm (0.47 in)	4 mm (0.16 in)
Spring force	7.65 ~ 10.01 N (780 ~ 1,021 g, 27.53 ~ 36.04 oz)	----
Commutator diameter	28 mm (1.10 in)	27 mm (1.06 in)
Mica undercut	0.7 mm (0.03 in)	----
Starter relay		
Model/manufacture	MS5F-561/JIDECO	----
Amperage rating	180 A	----
Coil winding resistance	4.18 ~ 4.62 Ω at 20 °C (68 °F)	----
Electric fan:		
Running rpm	6,350 r/min	----
Thermostat switch:		
Thermo unit		
Model/manufacture	4GB/DENSO	----
Circuit breakers:		
Type	Fuse	----
Amperage for individual circuit		
Main fuse	30 A × 1	----
Headlight fuse	15 A × 1	----
Ignition fuse	15 A × 1	----
Auxiliary DC jack fuse	10 A × 1	----
Four-wheel drive fuse	3 A × 1	----
Signaling system fuse	10 A × 1	----
Reserve	30 A × 1	----
Reserve	15 A × 1	----
Reserve	10 A × 1	----
Reserve	3 A × 1	----



LUBRICATION POINTS AND LUBRICANT TYPES


ENGINE

Lubrication points	Lubricant type
Oil seal lip (all)	
Bearing (all)	
O-ring (all)	
Crank pin	
Connecting rod (bearing)	
Piston surface/piston rings	
Piston pin	
Timing chain sprocket inner surface (crankshaft)	
Buffer boss	
Crankshaft seal	
Valve stem/valve stem end	
Rocker arm shaft	
Rocker arm	
Camshaft lobe/journal	
Cylinder head bolt	
Oil pump shaft, rotor, housing	
Oil filter cartridge O-ring	
Starter idle gear shaft	
Starter idle gear	
Starter one-way clutch bearing	
Clutch housing assembly shaft end	
Clutch housing	
One-way bearing	
Transmission gear (wheel/pinion)	
Axle (main/drive)	
Chain/sprocket (transmission)	
Damper cam (middle driven shaft)	
Gear coupling (middle driven shaft)	
Shift shaft	
Shift fork/guide bar	
Shift shaft stopper ball	
Shift lever collar	
Crankcase mating surface	Sealant (Quick Gasket®) Yamaha Bond No.1215
Stator lead grommet (left side crankcase)	Sealant (Quick Gasket®) Yamaha Bond No.1215



OIL FLOW DIAGRAMS



- ① Camshaft
- ② Crankshaft
- ③ Oil pump
- ④ Oil strainer






- ① Thermo unit
- ② Oil pump
- ③ Oil filter

- A To oil cooler
- B From oil cooler






- ① Crankshaft
- ② Oil filter





- ① Oil cooler
- ② Oil cooler outlet pipe
- ③ Oil cooler inlet pipe


- A From engine
- B To engine






CABLE ROUTING

- ① Rear brake switch lead
- ② Starter cable
- ③ Rear brake lever cable
- ④ Front brake hose
- ⑤ On-command four-wheel drive switch lead
- ⑥ On-command four-wheel drive switch
- ⑦ Throttle cable
- ⑧ Handlebar switch lead
- ⑨ Horn switch lead (for Europe and Oceania)
- ⑩ Horn switch (for Europe and Oceania)
- ⑪ Handlebar switch
- ⑫ Main switch lead
- ⑬ Differential gear case breather hose
- ⑭ Gear motor lead







- A Fasten the on-command four-wheel drive switch lead behind the handlebar with a plastic band.
- B Fasten the starter cable, handlebar switch lead, rear brake switch lead, and horn switch lead (for Europe and Oceania) behind the handlebar with a plastic band.
- C Fasten the handlebar switch lead, rear brake switch lead, and horn switch lead (for Europe and Oceania) behind the handlebar with a plastic band.
- D Fasten the gear motor lead, differential gear case breather hose, fan motor lead with a plastic band.
- E Loop the horn switch lead (for Europe and Oceania) around the plastic band as shown.
- F Fasten the on-command four-wheel drive switch lead, rear brake switch lead, main switch lead, and handlebar switch lead with a plastic band.





- ① Headlight lead
- ② Oil temperature warning light
- ③ Four-wheel drive indicator light
- ④ Differential gear case breather hose
- ⑤ Indicator light/speedometer light couplers
- ⑥ Speedometer cable
- ⑦ Wire harness


- A** Fasten the wire harness with a plastic band.
- B** Fasten the wire harness and speedometer cable with a plastic band.





- ① Fuel tank breather hose
- ② Starter cable
- ③ Cylinder head breather hose
- ④ Rear brake lever cable
- ⑤ Oil cooler hose
- ⑥ Gear motor lead
- ⑦ Differential gear case breather hose
- ⑧ Fan motor lead
- ⑨ Speedometer cable
- ⑩ Horn (for Europe and Oceania)
- ⑪ Horn lead (for Europe and Oceania)


- A** Insert the fuel tank breather hose into the hole of the handlebar cover.
- B** Fasten the starter cable with a plastic band.
- C** Fasten the brake lever cable and speedometer cable with a plastic band.
- D** Fasten the oil cooler hose and speedometer cable with a plastic band.
- E** Fasten the gear motor lead, differential gear case breather hose, and fan motor lead with a plastic band.






- ① Cylinder head breather hose
- ② Fuel hose
- ③ Final drive gear case breather hose
- ④ Rear brake breather hose
- ⑤ Wire harness
- ⑥ Starter motor lead
- ⑦ Negative battery lead
- ⑧ Rear brake lever cable
- ⑨ Air filter case check hose
- ⑩ Thermo unit lead
- ⑪ Speedometer cable

- ⑫ A.C. magneto lead
- ⑬ Rectifier/regulator
- ⑭ Reverse switch lead
- ⑮ Neutral switch lead
- ⑯ Carburetor drain hose
- ⑰ Float chamber air vent hose






- A** Fasten the wire harness with a plastic band.
- B** Fasten the wire harness, starter motor lead, and negative battery lead with a plastic band.
- C** Fasten the final drive gear case breather hose, rear brake breather hose, ground lead, and A.C. magneto lead with a plastic band.
- D** Fasten the rectifier/regulator lead and rear brake breather hose with a plastic band.
- E** Fasten the thermo unit lead and A.C. magneto lead with a plastic clamp.






- ① Throttle cable
- ② Spark plug lead
- ③ Main switch
- ④ Wire harness
- ⑤ Select lever control cable
- ⑥ Rear brake light switch lead
- ⑦ Rear brake pedal cable

- A** Fasten the select lever control cable, rear brake light switch lead, and spark plug lead with a plastic band.
- B** Fasten the select lever control cable and rear brake light switch lead with a plastic band.
- C** Fasten the oil cooler hose with a plastic band.





- ① Front brake hose
- ② Throttle cable
- ③ Wire harness
- ④ Final drive gear case breather hose
- ⑤ Rear brake breather hose
- ⑥ Float chamber air vent hose
- ⑦ Starter cable
- ⑧ Rear brake lever cable



EB300000

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

PERIODIC MAINTENANCE/LUBRICATION

ITEM	ROUTINE	INITIAL			EVERY	
		1 month	3 months	6 months	6 months	1 year
Valves*	<ul style="list-style-type: none"> • Check valve clearance. • Adjust if necessary. 	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Spark plug	<ul style="list-style-type: none"> • Check condition. • Adjust gap and clean. • Replace if necessary. 	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Air filter element	<ul style="list-style-type: none"> • Clean. • Replace if necessary. 	Every 20 ~ 40 hours (More often in wet or dusty areas.)				
Carburetor*	<ul style="list-style-type: none"> • Check and adjust idle speed/starter operation. • Adjust if necessary. 		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Crankcase breather system*	<ul style="list-style-type: none"> • Check breather hose for cracks or damage. • Replace if necessary. 			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Exhaust system*	<ul style="list-style-type: none"> • Check for leakage. • Tighten if necessary. • Replace gasket(s) if necessary. 			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Fuel line*	<ul style="list-style-type: none"> • Check fuel hose for cracks or damage. • Replace if necessary. 			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil	<ul style="list-style-type: none"> • Replace. (Warm engine before draining.) 	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil filter cartridge	<ul style="list-style-type: none"> • Replace. 	<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Engine oil strainer*	<ul style="list-style-type: none"> • Clean. 	<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Final gear oil	<ul style="list-style-type: none"> • Check for oil leakage. 	<input type="checkbox"/>				<input type="checkbox"/>
Differential gear oil	<ul style="list-style-type: none"> • Replace every 12 months. 					<input type="checkbox"/>
Front brake*	<ul style="list-style-type: none"> • Check operation/fluid leakage. (See NOTE page 35.) • Correct if necessary. 	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Rear brake	<ul style="list-style-type: none"> • Check operation. • Adjust if necessary. 	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
V-belt*	<ul style="list-style-type: none"> • Check operation. • Check for cracks or damage. 	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Wheels*	<ul style="list-style-type: none"> • Check balance/damage/runout. • Repair if necessary. 	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Wheel bearing*	<ul style="list-style-type: none"> • Check bearing assemblies for looseness/damage. • Replace if damaged. 	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Front and rear suspension*	<ul style="list-style-type: none"> • Check operation. • Correct if necessary. 			<input type="checkbox"/>		<input type="checkbox"/>
Steering system*	<ul style="list-style-type: none"> • Check operation./Replace if damaged. • Check toe-in./Adjust if necessary. 	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Drive shaft universal joint*	<ul style="list-style-type: none"> • Lubricate. 			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Axle boots*	<ul style="list-style-type: none"> • Check operation. • Replace if damaged. 	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

PERIODIC MAINTENANCE/LUBRICATION



ITEM	ROUTINE	INITIAL			EVERY	
		1 month	3 months	6 months	6 months	1 year
Fittings and fasteners*	<ul style="list-style-type: none"> • Check all chassis fittings and fasteners. • Correct if necessary. 	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Lights and switches*	<ul style="list-style-type: none"> • Check operation. • Adjust headlight beams. 	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.


NOTE: _____

- Recommended brake fluid: DOT 4
- Brake fluid replacement:
 - When disassembling the master cylinder or caliper, replace the brake fluid. Normally check the brake fluid level and add fluid as required.
 - On the inner parts of the master cylinder and caliper, replace the oil seals every two years.
 - Replace the brake hoses every four years, or if cracked or damaged.


⚠ WARNING _____

Indicates a potential hazard that could result in serious injury or death.

SEAT, CARRIERS, FENDERS AND FUEL TANK
SEAT, FRONT CARRIER, FRONT BUMPER AND FRONT FENDER




Order	Job name/Part name	Q'ty	Remarks
	Removing the seat, front carrier, front bumper and front fender		Remove the parts in the order below.
1	Seat	1	NOTE: _____ Pull up the seat lock lever, then pull up on the rear of the seat. _____
2	Front carrier	1	
3	Engine skid plate	1	
4	Front bumper	1	
5	Headlight coupler	2	Disconnect.
6	Front fender	1	
7	Main switch coupler	1	Disconnect.
8	Handlebar cover	1	
9	Fuel tank cover	1	




Order	Job name/Part name	Q'ty	Remarks
10	Indicator lights assembly coupler	2	Disconnect.
11	Speedometer cable	1	
12	Meter assembly	1	
			For installation, reverse the removal procedure.



FUEL TANK



Order	Job name/Part name	Q'ty	Remarks
	Removing the fuel tank Seat and fuel tank cover		Remove the parts in the order below. Refer to "SEAT, CARRIERS, FENDERS AND FUEL TANK".
1	Fuel hose	1	NOTE: _____ Before disconnecting the fuel hose, turn the fuel cock to "OFF".
2	Fuel cock lever	1	
3	Fuel tank	1	NOTE: _____ When installing the fuel tank, pass the fuel tank breather hose through the hole of the handlebar protector.
4	Plastic band	4	
5	Rubber cover	1	
			For installation, reverse the removal procedure.




ENGINE

CHECKING THE OIL TEMPERATURE WARNING LIGHT


- ① Oil temperature warning light

Oil temperature warning light checking method




ENGINE

CYLINDER HEAD 




Order	Job name/Part name	Q'ty	Remarks
	Removing the cylinder head		Remove the parts in the order below.
	Fuel tank/rubber cover		Refer to "SEAT, CARRIERS, FENDERS AND FUEL TANK". Refer to "ENGINE REMOVAL" in CHAPTER 4. (Manual No.: 5TE2-AE1) Refer to "CARBURETOR" in CHAPTER 6. (Manual No.: 5TE2-AE1) Refer to "ADJUSTING THE VALVE CLEARANCE" in CHAPTER 3. (Manual No.: 5TE2-AE1)
	Front fender		
	Air duct assembly 1/air filter case		
	Exhaust pipe/muffler		
	Carburetor assembly		
	Recoil starter/timing plug		
1	Spark plug lead	1	
2	Spark plug	1	
3	Engine mounting bolt (upper)/nut	1/1	
4	Engine bracket (upper)	1	




Order	Job name/Part name	Q'ty	Remarks
5	Cylinder head breather hose	1	Refer to "REMOVING THE CYLINDER HEAD" and "INSTALLING THE CYLINDER HEAD" in CHAPTER 4. (Manual No.: 5TE2-AE1) For installation, reverse the removal procedure.
6	Camshaft sprocket cover/O-ring	1/1	
7	Tappet cover/O-ring	2/2	
8	Timing chain tensioner cap bolt	1	
9	Timing chain tensioner/gasket	1/1	
10	Camshaft sprocket	1	
11	Cylinder head	1	
12	Cylinder head gasket	1	
13	Dowel pin	2	
14	Gasket	1	
15	Timing chain guide (exhaust)	1	



CAMSHAFT, ROCKER ARMS AND VALVES




Order	Job name/Part name	Q'ty	Remarks
	Removing the camshaft, rocker arms and valves		Remove the parts in the order below.
1	Intake manifold/O-ring	1/1	Refer to "REMOVING THE CAMSHAFT AND ROCKER ARMS" and "INSTALLING THE CAMSHAFT AND ROCKER ARMS" in CHAPTER 4. (Manual No.: 5TE2-AE1)
2	Oil gallery bolt	1	
3	Lock washer/bearing retainer	1/1	
4	Camshaft	1	
5	Rocker arm shaft/O-ring	2/2	
6	Rocker arm	2	
7	Locknut/valve adjuster	2/2	



Order	Job name/Part name	Q'ty	Remarks
8	Valve cotter	4	Refer to "REMOVING THE VALVES AND VALVE SPRINGS" and "INSTALLING THE VALVES AND VALVE SPRINGS" in CHAPTER 4. (Manual No.: 5TE2-AE1) For installation, reverse the removal procedure.
9	Valve spring retainer	2	
10	Valve spring (outer)	2	
11	Valve spring (inner)	2	
12	Valve (intake)	1	
13	Valve (exhaust)	1	
14	Valve stem seal	2	
15	Valve spring seat	2	




CYLINDER AND PISTON




Order	Job name/Part name	Q'ty	Remarks
	Removing the cylinder and piston		
1	Cylinder head Cylinder/O-ring	1/1	Remove the parts in the order below. Refer to "CYLINDER HEAD". Refer to "INSTALLING THE CYLINDER" in CHAPTER 4. (Manual No.: 5TE2-AE1)
2	Cylinder gasket	1	
3	Dowel pin	1	
4	Dowel pin/O-ring	1/1	
5	Piston pin clip	2	Refer to "REMOVING THE PISTON" and "INSTALLING THE PISTON" in CHAPTER 4. (Manual No.: 5TE2-AE1)
6	Piston pin	1	
7	Piston	1	
8	Piston ring set	1	
			For installation, reverse the removal procedure.



RECOIL STARTER AND A.C. MAGNETO




Order	Job name/Part name	Q'ty	Remarks
	Removing the A.C. magneto		Remove the parts in the order below.
	Engine oil		Drain. Refer to "CHANGING THE ENGINE OIL" in CHAPTER 3. (Manual No.: 5TE2-AE1)
	Seat and fuel tank cover		Refer to "SEAT, CARRIERS, FENDERS AND FUEL TANK".
	Left footrest board		Refer to "FOOTREST BOARDS" in CHAPTER 3. (Manual No.: 5TE2-AE1)
1	Recoil starter assembly	1	Refer to "REMOVING THE A.C. MAGNETO" and "INSTALLING THE A.C. MAGNETO" in CHAPTER 4. (Manual No.: 5TE2-AE1)
2	A.C. magneto coupler	2	
3	Starter pulley	1	
4	Oil filler cap	1	
5	Crankcase cover/gasket	1/1	
6	Dowel pin	2	




Order	Job name/Part name	Q'ty	Remarks
7	Lead holder	1	
8	Pickup coil	1	
9	Stator assembly	1	
10	Starter idle gear shaft	1	
11	Starter idle gear	1	
12	Rotor	1	Refer to "REMOVING THE A.C. MAGNETO" and "INSTALLING THE A.C. MAGNETO" in CHAPTER 4. (Manual No.: 5TE2-AE1).
13	Starter wheel gear	1	
14	Woodruff key	1	
15	Washer	1	



BALANCER GEARS AND OIL PUMP




Order	Job name/Part name	Q'ty	Remarks
	Removing the balancer gears and oil pump		Remove the parts in the order below.
	Starter wheel gear		Refer to "RECOIL STARTER AND A.C. MAGNETO".
1	Plate	1	Refer to "REMOVING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR" and "INSTALLING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR".
2	Nut/lock washer	1/1	
3	Balancer driven gear	1	
4	Straight key	1	
5	Spacer	1	
6	Plate	1	




Order	Job name/Part name	Q'ty	Remarks
7	Balancer drive gear	1	For installation, reverse the removal procedure.
8	Spring	8	
9	Pin	4	
10	Oil pump assembly/gasket	1/1	



OIL PUMP



Order	Job name/Part name	Q'ty	Remarks
	Disassembling the oil pump		Remove the parts in the order below.
①	Rotor cover	1	
②	Pin	1	
③	Oil pump driven gear	1	
④	Inner rotor	1	
⑤	Outer rotor	1	
⑥	Oil pump housing	1	
			For assembly, reverse the disassembly procedure.




REMOVING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR

1. Straighten the lock washer tabs.
2. Loosen:
 - Balancer driven gear nut ①


NOTE:

Place an aluminum plate ② between the teeth of the balancer drive gear ③ and balancer driven gear ④.




REMOVING THE BALANCER DRIVE GEAR AND BUFFER BOSS

1. Remove:
 - Plate ①
 - Balancer drive gear ②
 - Springs ③
 - Pins ④




CHECKING THE OIL PUMP DRIVEN GEAR

1. Check:
 - Oil pump driven gear ①
 Cracks/wear/damage → Replace.



CHECKING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR

1. Check:
 - Balancer drive gear ①
 - Balancer driven gear ②
 Damage/wear → Replace the balancer drive gear and balancer driven gear as a set.
 Excessive noise during operation → Replace the balancer drive gear and balancer driven gear as a set.




INSTALLING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR

1. Install:

- Pin
- Spring
- Balancer drive gear (onto the buffer boss)

NOTE: _____

Align the punch mark (a) on the balancer drive gear with the keyway (b) on the crankshaft.




2. Install:

- Plate

NOTE: _____

Install the plate with the identification mark "F" facing away from the balancer drive gear.




3. Install:

- Balancer driven gear

NOTE: _____

Align the punch mark (a) on the balancer drive gear with the punch mark (b) on the balancer driven gear.



4. Install:

- Lock washer **New**
- Balancer driven gear nut (1)

60 Nm (6.0 m • kg, 43 ft • lb)

NOTE: _____


- Place an aluminum plate (2) between the teeth of the balancer drive gear (3) and balancer driven gear (4).

- Apply the molybdenum disulfide grease to the thread of axles and nuts.


5. Bend the lock washer tabs along the balancer driven gear nut.



OIL COOLER




Order	Job name/Part name	Q'ty	Remarks
	Removing the oil cooler		Remove the parts in the order below.
	Seat, fuel tank cover, front carrier, front bumper and front fender		Refer to "SEAT, CARRIERS, FENDERS AND FUEL TANK".
	Left footrest board		Refer to "FOOTREST BOARDS" in CHAPTER 3.
	Engine oil		(Manual No.: 5TE2-AE1) Drain. Refer to "CHANGING THE ENGINE OIL" in CHAPTER 3.
			(Manual No.: 5TE2-AE1)
1	Oil cooler fan coupler	1	Disconnect.
2	Oil inlet hose/O-ring	1/1	Disconnect.




Order	Job name/Part name	Q'ty	Remarks
3	Oil outlet hose/O-ring	1/1	Disconnect.
4	Oil cooler	1	
5	Oil cooler fan	1	
6	Oil hose protector	1	
			For installation, reverse the removal procedure.



PRIMARY AND SECONDARY SHEAVES




Order	Job name/Part name	Q'ty	Remarks
	Removing the primary and secondary sheaves		Remove the parts in the order below.
	Front fender		Refer to "SEAT, CARRIERS, FENDERS AND FUEL TANK".
	Rear fender		Refer to "SEAT, CARRIERS, FENDERS AND FUEL TANK" in CHAPTER 3. (Manual No.: 5TE2-AE1)
	Right footrest board		Refer to "FOOTREST BOARDS" in CHAPTER 3. (Manual No.: 5TE2-AE1)
1	Drive belt case cover	1	
2	Rubber gasket	1	
3	Bearing housing	1	
4	Dowel pin	2	



Order	Job name/Part name	Q'ty	Remarks
5	Primary sliding sheave assembly	1	Refer to "REMOVING THE PRIMARY AND SECONDARY SHEAVES" and "INSTALLING THE PRIMARY AND SECONDARY SHEAVES" in CHAPTER 4. (Manual No.: 5TE2-AE1)
6	V-belt	1	
7	Primary fixed sheave	1	
8	Secondary sheave assembly	1	
9	Drive belt case	1	For installation, reverse the removal procedure.
10	Rubber gasket	1	




PRIMARY SLIDING SHEAVE




Order	Job name/Part name	Q'ty	Remarks
	Disassembling the primary sliding sheave		Remove the parts in the order below.
①	Primary sliding sheave cap	1	Refer to "ASSEMBLING THE PRIMARY SHEAVE".
②	Primary pulley slider	3	
③	Spacer	3	
④	Primary pulley cam	1	
⑤	Primary pulley weight	6	
⑥	Collar	1	
⑦	Oil seal	2	
⑧	Primary sliding sheave	1	
⑨	O-ring	1	
			For assembly, reverse the disassembly procedure.



SECONDARY SHEAVE



Order	Job name/Part name	Q'ty	Remarks
	Disassembling the secondary sheave		Remove the parts in the order below.
①	Nut	1	Refer to "DISASSEMBLING THE SECONDARY SHEAVE" in CHAPTER 4. (Manual No.: 5TE2-AE1) Refer to "ASSEMBLING THE SECONDARY SHEAVE". For assembly, reverse the disassembly procedure.
②	Spring seat	1	
③	Compression spring	1	
④	Spring seat	1	
⑤	Guide pin	3	
⑥	Secondary sliding sheave	1	
⑦	O-ring	2	
⑧	Secondary fixed sheave	1	
⑨	Oil seal	2	




ASSEMBLING THE PRIMARY SHEAVE

1. Clean:

- Primary sliding sheave face ①
- Primary fixed sheave face ②
- Collar ③
- Weights ④
- Primary pulley cam face

NOTE:

Remove any excess grease.




2. Install:

- Weights ①

NOTE:


- Apply Yamaha Grizzly grease (90 g) to the whole outer surface of the weights and install.
- Apply Yamaha Grizzly grease to the inner surface of the collar.
- Apply Yamaha Grizzly grease to the inner surface of the primary sliding sheave.



3. Install:

- Spacer
- Sliders ①
- Primary pulley cam ②
- Primary sliding sheave cap


3 Nm (0.3 m • kg, 2.2 ft • lb)



ASSEMBLING THE SECONDARY SHEAVE

1. Apply:

- BEL-RAY assembly lube®
(to the secondary sliding sheave ① inner surface and oil seals)




2. Install:


- Secondary sliding sheave ①
- Secondary fixed sheave ②

NOTE:


Align the alignment mark ① on the secondary sliding sheave with the hole ② in the guide pin that is aligned with the rivet ③ on the secondary fixed sheave.



- 3.Install:
- Guide pins ①



- 4.Apply:
- BEL-RAY assembly lube®
(to all guide pin sliding grooves ①, and O-rings ② **New**)



- 5.Install:
- Spring seat
 - Compression spring
 - Spring seat
 - Nut

Installing steps:

- Attach the sheave fixed block, locknut wrench and sheave spring compressor to the secondary sheave assembly.

	Sheave fixed block:
	P/N. YM-04135, 90890-04135
	Locknut wrench:
	P/N. YM-01348, 90890-01348
	Sheave spring compressor:
	P/N. YM-04134, 90890-04134


- Place the sheave fixed block in a vise and secure it.
- Tighten the sheave spring compressor nut ① and compress the spring.
- Install the nut ② and tighten it to the specified torque using the locknut wrench.

	Nut:
	90 Nm (9.0 m • kg, 65 ft • lb)


- Remove the sheave spring compressor, locknut wrench, and sheave fixed block.



CLUTCH



Order	Job name/Part name	Q'ty	Remarks
	Removing the clutch Primary and secondary sheaves		Remove the parts in the order below. Refer to "PRIMARY AND SECONDARY SHEAVES".
1	Clutch housing assembly	1	Refer to "REMOVING THE CLUTCH" and "INSTALLING THE CLUTCH" in CHAPTER 4. (Manual No.: 5TE2-AE1)
2	Gasket	1	
3	One-way clutch bearing	1	
4	Nut	1	
5	Clutch carrier assembly	1	
			For installation, reverse the removal procedure.




Order	Job name/Part name	Q'ty	Remarks
	Disassembling the clutch housing		Remove the parts in the order below.
①	Oil seal	1	
②	Circlip	1	
③	Bearing housing	1	
④	Circlip	1	
⑤	Bearing	1	
⑥	Circlip	1	
⑦	Bearing	1	
⑧	Clutch housing	1	
			For assembly, reverse the disassembly procedure.




CRANKCASE

STARTER MOTOR, TIMING CHAIN AND OIL FILTER




Order	Job name/Part name	Q'ty	Remarks
	Removing the starter motor, timing chain and oil filter		Remove the parts in the order below.
	Engine assembly		Refer to "ENGINE REMOVAL" in CHAPTER 4.
	Cylinder head		Refer to "CYLINDER HEAD".
	Cylinder and piston		Refer to "CYLINDER AND PISTON".
	Recoil starter and rotor		Refer to "RECOIL STARTER AND A.C. MAGNETO".
	Balancer gears and oil pump		Refer to "BALANCER GEARS AND OIL PUMP".
	Primary and secondary sheaves		Refer to "PRIMARY AND SECONDARY SHEAVES".
	Clutch carrier assembly		Refer to "CLUTCH".
1	Timing chain guide (intake)	1	
2	Timing chain	1	



Order	Job name/Part name	Q'ty	Remarks
3	Starter motor/O-ring	1/1	
4	Oil filter cartridge	1	
5	Plate	1	
6	Spring	1	
7	Check ball	1	
8	Neutral switch	1	
9	Reverse switch	1	
10	Thermo unit	1	
11	Speedometer gear unit	1	
			For installation, reverse the removal procedure.




CRANKCASE






Order	Job name/Part name	Q'ty	Remarks
	Separating the crankcase		Remove the parts in the order below.
1	Shift lever assembly	1	Refer to "SEPARATING THE CRANKCASE" and "ASSEMBLING THE CRANKCASE". For installation, reverse the removal procedure.
2	Crankcase (left)	1	
3	Dowel pin	2	
4	Crankcase (right)	1	
5	Spacer	1	
6	Crankshaft seal	2	
7	Spacer	1	



CRANKCASE BEARINGS



Order	Job name/Part name	Q'ty	Remarks
	Removing the crankcase bearings		Remove the parts in the order below.
	Crankshaft and balancer		Refer to "CRANKSHAFT".
	Transmission		Refer to "TRANSMISSION".
	Middle drive/driven shaft		Refer to "MIDDLE GEAR".
1	O-ring/collar	1/1	
2	Oil seal	2	
3	Bearing retainer	2	
4	Bearing	9	
			For installation, reverse the removal procedure.



SEPARATING THE CRANKCASE

1. Separate:
- Left crankcase
 - Right crankcase

Separation steps:

- Remove the crankcase bolts.

NOTE:

- Loosen each bolt 1/4 of a turn at a time and after all the bolts are loosened, remove them.
- Loosen the bolts in stages, using a crisscross pattern.

- Ⓐ Left crankcase
- Ⓑ Right crankcase

ASSEMBLING THE CRANKCASE

1. Apply:
- Sealant (Quick Gasket®) ① (to the mating surfaces of both case halves)





Sealant (Quick Gasket®):
P/N. ACC-11001-05-01
Yamaha bond No. 1215:
P/N. 90890-85505

2. Install:
- Dowel pins ②
3. Fit the right crankcase onto the left case. Tap lightly on the case with a soft hammer.

CAUTION:

Before installing and torquing the crankcase holding bolts, be sure to check whether the transmission is functioning properly by manually rotating the shift shaft in both directions.



4. Tighten:

- Crankcase bolts ①

20 Nm (2.0 m • kg, 14 ft • lb)

(follow the proper tightening sequence)

- Crankcase bolts ②

10 Nm (1.0 m • kg, 7.2 ft • lb)

(follow the proper tightening sequence)

A Right crankcase

B Left crankcase

NOTE:

Tighten the bolts in stages, using a crisscross pattern.

5. Apply:


- 4-stroke engine oil
(to the crank pin, bearings and oil delivery hole)

6. Check:


- Crankshaft and transmission operation
Unsmooth operation → Repair.



CRANKSHAFT



Order	Job name/Part name	Q'ty	Remarks
	Removing the crankshaft		
	Crankcase separation		Remove the parts in the order below. Refer to "CRANKCASE".
1	Oil strainer	1	
2	Balancer	1	Refer to "REMOVING THE CRANKSHAFT" and "INSTALLING THE CRANKSHAFT".
3	Crankshaft	1	For installation, reverse the removal procedure.




REMOVING THE CRANKSHAFT

1. Remove:

- Crankshaft seal ①

NOTE:

Mark a note of the position of each crankshaft seal so that they can be installed in the correct place and in the correct direction.




2. Remove:

- Crankshaft
- Use a crankcase separating tool ①.



Crankcase separating tool:
P/N. YU-01135-A, 90890-01135



INSTALLING THE CRANKSHAFT

1. Install:

- Crankshaft



Crankshaft installer pot ①:
P/N. 90890-01274

Crankshaft installer bolt ②:
P/N. 90890-01275

Crankshaft installer set ③:
P/N. YU-90050

Adapter ④:
P/N. YM-1383, 90890-01383

Spacer (crankshaft installer) ⑤:
P/N. YM-91044, 90890-04081

Spacer ⑥:
P/N. 90890-01309

NOTE:


Hold the connecting rod at the Top Dead Center (T.D.C.) with one hand while turning the nut of the installing tool with the other. Operate the installing tool until the crankshaft bottoms against the bearing.

CAUTION:


Apply engine oil to each bearing to protect the crankshaft against scratches and to make installation easier.



TRANSMISSION



Order	Job name/Part name	Q'ty	Remarks
	Removing the transmission		
	Crankcase separation		Remove the parts in the order below. Refer to "CRANKCASE".
1	Driven sprocket	1	
2	Chain	1	
3	Secondary shaft	1	
4	Guide bar	1	
5	Shift fork	1	
6	Clutch dog	1	
7	Drive axle assembly	1	
8	Shift shaft stopper	1	
9	Shift shaft	1	
			For installation, reverse the removal procedure.


**INSTALLING THE TRANSMISSION**

1. Install:

- Shift shaft ①
- Drive axle assembly ②
- Clutch dog ③
- Shift fork ④
- Guide bar ⑤

NOTE:

Install the shift fork with the "L" mark facing towards the left side of the crankcase. Be sure that the shift fork guide pin is properly seated in the shift shaft groove.



2. Check:


- Shift operation
- Unsmooth operation → Repair.

NOTE:

- Oil each gear and bearing thoroughly.
- Before assembling the crankcase, be sure that the transmission is in neutral and that the gears turn freely.




MIDDLE GEAR
MIDDLE DRIVE SHAFT




Order	Job name/Part name	Q'ty	Remarks
	Removing the middle drive shaft		
	Crankcase separation		Remove the parts in the order below. Refer to "CRANKCASE".
1	Bearing housing assembly	1	
2	Middle driven gear	1	
3	Nut	1	Refer to "REMOVING THE MIDDLE DRIVE SHAFT" and "INSTALLING THE MIDDLE DRIVE SHAFT" in CHAPTER 4. (Manual No.: 5TE2-AE1)
4	Middle drive pinion gear	1	
5	Shim		Refer to "SELECTING THE MIDDLE DRIVE AND DRIVEN GEAR SHIMS".
6	Middle drive shaft	1	
7	Bearing retainer	2	
			For installation, reverse the removal procedure.




MIDDLE DRIVEN SHAFT



Order	Job name/Part name	Q'ty	Remarks
	Removing the middle driven shaft		
	Crankcase separation		Remove the parts in the order below. Refer to "CRANKCASE".
1	Circlip	2	Refer to "REMOVING THE MIDDLE DRIVEN SHAFT" and "INSTALLING THE MIDDLE DRIVEN SHAFT" in CHAPTER 4. (Manual No.: 5TE2-AE1)
2	Bearing	2	
3	Universal joint	1	
4	Universal joint yoke	1	
5	Bearing housing/O-ring	1/1	
6	Shim		Refer to "SELECTING THE MIDDLE DRIVE AND DRIVEN GEAR SHIMS".
7	Middle driven pinion gear	1	Refer to "REMOVING THE MIDDLE DRIVEN SHAFT" and "INSTALLING THE MIDDLE DRIVEN SHAFT" in CHAPTER 4. (Manual No.: 5TE2-AE1)
8	Bearing retainer	1	
9	Damper cam	1	
10	Spring	1	
11	Gear coupling	1	



Order	Job name/Part name	Q'ty	Remarks
12	Front drive shaft coupling	1	For installation, reverse the removal procedure.
13	Bearing retainer	1	
14	Middle driven shaft	1	



SELECTING THE MIDDLE DRIVE AND DRIVEN GEAR SHIMS

When the drive and driven gear, bearing housing assembly and/or crankcase are replaced, be sure to adjust the gear shims.

1. Select:

- Middle drive gear shim ①
- Middle driven gear shim ②

Selection steps:

- Position middle drive and driven gear by using shims ① and ② with their respective thickness calculated from information marked on crankcase, bearing housing and drive gear end.

- ① Shim thickness "A"
- ② Shim thickness "B"




- To find shim thickness "A", use following formula:

Middle drive pinion gear shim thickness:

$$"A" = d - a - b - c$$

Where:

- ① = a numeral (usually a decimal number) on the bearing housing is either added to or subtracted from "4.5".
- ② = 15.0
- ③ = drive pinion gear to driven pinion gear center distance (considered constant "55").
- ④ = a numeral (usually a decimal number) on the right crankcase specifies a thickness of "75".





Example:

- 1) If the bearing housing is marked “-2”,
..... ① is 4.48.
- 2) ② is 15.0
- 3) ③ is 55
- 4) If the crankcase (right) is marked “75.01”,
..... ④ is 75.01.
- 5) Therefore, the shim thickness is 0.53 mm.

$$A = 75.01 - 4.48 - 15.0 - 55$$

$$= 0.53$$

- 6) Round off hundredths digit and select appropriate shim(s).

In the example above, the calculated shim thickness is 0.53 mm. The chart instructs you, however, to round off 3 to 5.






Hundredths	Round value
0, 1, 2	0
3, 4, 5, 6, 7	5
8, 9	10

Shims are supplied in the following thicknesses.

Thickness (mm)	Middle drive pinion gear shim	
	0.10	0.30
0.15	0.40	
0.20	0.50	

- To find shim thickness “B” use the following formula:

Middle driven pinion gear shim thickness:
“B” = ⑤ - ⑥ + ⑧ - ⑨ - ⑩ - 0.05



Where:

- ⓔ = a numeral (usually a decimal number) on the bearing housing is either added to or subtracted from “76”.
- ⓕ = a numeral (usually a decimal number) on the middle driven pinion gear is either added to or subtracted from “59”.
- ⓖ = a numeral (usually a decimal number) on the middle driven pinion gear is either added to or subtracted from “79.5”.
- ⓗ = a numeral (usually a decimal number) on the left crankcase specifies a thickness of “72.01”.
- Ⓢ = a numeral (usually a decimal number) on the right crankcase specifies a thickness of “23.87”.

Example:

- 1) If the bearing housing is marked “+02”, ⓔ is 76.02.
- 2) If the driven pinion gear is marked “+02”, ⓕ is 59.02.
- 3) If the driven pinion gear is marked “+02”, ⓖ is 79.52.
- 4) If the crankcase (left) is marked “72.01”, ⓗ is 72.01.
- 5) If the crankcase (right) is marked “23.87”, Ⓢ is 23.87.
- 6) Therefore, the shim thickness is 0.64 mm.


$$B = 76.02 - 59.02 + 79.52 - 72.01 - 23.87 - 0.05 = 0.64$$

- 7) Round off hundredths digit and select appropriate shim(s).
In the example above, the calculated shim thickness is 0.64 mm. The chart instructs you, however, to round off 4 to 5.

Hundredths	Round value
0, 1, 2	0
3, 4, 5, 6, 7	5
8, 9	10




Shims are supplied in the following thickness.

	Middle drive pinion gear shim	
Thickness (mm)	0.10	0.40
	0.15	0.50
	0.20	0.60
	0.30	



DRIVE TRAIN

FRONT CONSTANT VELOCITY JOINTS AND DIFFERENTIAL GEAR






Order	Job name/Part name	Q'ty	Remarks
	Removing the front constant velocity joints and differential gear		Remove the parts in the order below.
	Engine skid plate (front)		Refer to "SEAT, CARRIERS, FENDERS AND FUEL TANK".
	Front fender		
	Brake light switch cover		Refer to "FRONT BRAKE" in CHAPTER 8. (Manual No.: 5TE2-AE1)
	Differential gear oil		Drain. Refer to "CHANGING THE DIFFERENTIAL GEAR OIL" in CHAPTER 3. (Manual No.: 5TE2-AE1)
	Steering knuckle		Refer to "STEERING SYSTEM" in CHAPTER 8. (Manual No.: 5TE2-AE1)
	Front arms (lower)		Refer to "FRONT ARMS AND FRONT SHOCK ABSORBERS".
1	Constant velocity joint	2	

FRONT CONSTANT VELOCITY JOINTS AND DIFFERENTIAL GEAR



Order	Job name/Part name	Q'ty	Remarks
2	Gear motor coupler/four-wheel drive switch connector	1/1	Disconnect.
3	Differential gear case breather hose	1	Disconnect.
4	Differential gear	1	
5	Drive shaft	1	
6	Compression spring	1	
7	Coupling gear	1	
			For installation, reverse the removal procedure.



MEASURING AND ADJUSTING THE DIFFERENTIAL GEAR LASH

Measuring the differential gear lash

1. Secure the gear case in a vise or another supporting device.
2. Remove:
 - Drain plug
 - Gasket
3. Install:
 - A bolt of the specified size ① (into the drain plug hole)

CAUTION:

Finger tighten the bolt until it holds the ring gear. Otherwise, the ring gear will be damaged.

4. Attach:

- Gear lash measurement tool ①
- Dial gauge ②



**Gear lash measurement tool:
P/N. YM-01475, 90890-01475**

① Measuring point is 25 mm (0.98 in)

5. Measure:


- Gear lash
- Gently rotate the gear coupling from engagement to engagement.



**Differential gear lash:
0.05 ~ 0.25 mm
(0.0020 ~ 0.0098 in)**

NOTE:

Measure the gear lash at four positions. Rotate the shaft 90° each time.



Adjusting differential gear lash

1.Remove:

- Shim(s) (left) ①
- Differential gear assembly ②
- Shim(s) (right) ③

2.Adjust:


- Gear lash

Adjustment steps:

- Select the suitable shims using the following chart.

Too little gear lash	Reduce shim thickness.
Too large gear lash	Increase shim thickness.


- If it is necessary to increase by more than 0.05 mm (0.002 in):
Reduce right shim thickness by 0.1 mm (0.004 in) for every 0.1 mm (0.004 in) of left shim increase.
- If it is necessary to reduce by more than 0.1 mm (0.004 in):
Increase right shim thickness by 0.1 mm (0.004 in) for every 0.1 mm of left shim decrease.

	Ring gear shim (left and right)		
Thickness (mm)	0.1	0.2	0.3
	0.4	0.5	1.0




CHASSIS


REAR BRAKE



Order	Job name/Part name	Q'ty	Remarks
	Removing the rear brake drum		
	Rear wheel (left)		Remove the parts in the order below. Refer to "FRONT AND REAR WHEELS" in CHAPTER 8. (Manual No.: 5TE2-AE1)
1	Brake drum cover	1	Refer to "REMOVING THE REAR BRAKE" in CHAPTER 8. (Manual No.: 5TE2-AE1) Refer to "INSTALLING THE REAR BRAKE".
2	Dust seal	1	
3	Brake drum	1	
4	Adjusting nut	2	
5	Pin	2	
6	Spring	2	
7	Rear brake lever cable	1	
8	Rear brake pedal cable	1	
9	Cotter pin	2	
10	Plate	1	
11	Brake shoe	2	
12	Brake shoe spring	2	




Order	Job name/Part name	Q'ty	Remarks
13	Brake camshaft lever	1	Refer to "REMOVING THE REAR BRAKE" in CHAPTER 8. (Manual No.: 5TE2-AE1) Refer to "INSTALLING THE REAR BRAKE".
14	Brake shoe wear indicator	1	
15	Brake camshaft	1	
16	O-ring	2	
17	Dust seal	1	
18	Brake shoe plate	1	
			For installation, reverse the removal procedure.



CHECKING THE REAR BRAKE


1. Check:

- Brake drum ①
Cracks/damage → Replace.
- Splines ②
Wear/damage → Replace.



2. Check:

- Brake shoe plate ①
- Pivot pins ②
- Brake camshaft ③
Bends/cracks/damage → Replace.
- Dust seal ④
Wear/damage → Replace.




3. Check:

- Brake shoes ①
- Brake shoe springs ②
Cracks/damage → Replace as a set.

NOTE: _____

When replacing the brake shoes, replace the brake shoe springs at the same time.




4. Check:

- Brake shoe lining
Glazed areas → Repair.
Sand the glazed areas with coarse sandpaper.

NOTE: _____

After sanding the glazed areas, clean the brake shoe with a cloth.



5.Measure:

- Brake shoe lining thickness ①
- Out of specification → Replace.


① Measuring points

NOTE:

Replace the brake shoes as a set if either is worn to the wear limit.



**Brake shoe lining thickness limit:
2.0 mm (0.08 in)**




6.Measure:

- Brake drum inside diameter ①
- Out of specification → Replace.




**Brake drum inside diameter limit
(maximum):
161 mm (6.34 in)**



7.Check:

- Brake drum inner surface
- Oil deposits → Clean.
Remove the oil with a rag soaked in lacquer thinner or solvent.
- Scratches → Repair.
Lightly and evenly polish the scratches with an emery cloth.



INSTALLING THE REAR BRAKE

1.Lubricate:

- Brake camshaft ①
- Pivot pins ②




Lithium-soap-based grease



CAUTION:


During installation, lightly grease the brake camshaft and the pivot pin. Wipe off the excess grease.



2. Install:
- Brake shoe wear indicator ①

NOTE:

When installing the wear indicator pointer, fit the projection into a brake camshaft groove and align the pointer with the right end of the wear indicator scale ②.



3. Install:
- Brake camshaft lever ①



Bolt (camshaft lever):
9 Nm (0.9 m • kg, 6.5 ft • lb)


NOTE:

When installing the brake camshaft lever, align the punch marks ② on the brake camshaft lever and brake camshaft.

4. Apply:
- Sealant ③
(onto the mating surfaces of swingarm)




Sealant (Quick Gasket)®:
P/N. ACC-11001-05-01
Yamaha bond No. 1215:
P/N. 90890-85505



5. Install:
- Brake shoe plate ①
 - Bearing retainer ②
 - Brake shoes ③
 - Spring ④
 - Plate ⑤
 - Cotter pins ⑥ **New**



Bolt (bearing retainer):
28 Nm (2.8 m • kg, 20 ft • lb)



6. Check:


- Brake camshaft operation
Unsmooth operation → Repair.

7. Lubricate:

- Dust seal ①



Lithium-soap-based grease



8. Connect:

- Rear brake lever cable ①
- Rear brake pedal cable ②

9. Install:

- Springs ③
- Pins ④
- Adjusting nuts ⑤
- Brake drum
- Brake drum cover

10. Install:

- Rear wheel hub (left)
- Rear wheel (left)
Refer to “FRONT AND REAR WHEELS” in CHAPTER 8. (Manual No.: 5TE2-AE1)




Axle nut:
150 Nm (15 m • kg, 110 ft • lb)
Nut (rear wheel):
55 Nm (5.5 m • kg, 40 ft • lb)


11. Adjust:

- Rear brake pedal free play
- Rear brake lever free play
Refer to “ADJUSTING THE REAR BRAKE” in CHAPTER 3. (Manual No.: 5TE2-AE1)

STEERING SYSTEM
STEERING STEM




Order	Job name/Part name	Q'ty	Remarks
	Removing the steering stem		
	Handlebar		Remove the parts in the order below. Refer to "HANDLEBAR" in CHAPTER 8. (Manual No.: 5TE2-AE1)
	Seat] Refer to "SEAT, CARRIERS, FENDERS AND FUEL TANK".
	Front fender		
1	Lock washer	1] Refer to "INSTALLING THE CABLE GUIDE" in CHAPTER 8. (Manual No.: 5TE2-AE1)
2	Cable guide	1	
3	Steering stem bushing	2	
4	Collar	2	
5	Oil seal	2	
6	Tie rod end nut	2	
7	Tie rod	2	Disconnect.
8	Steering stem nut	1	
9	Pitman arm	1	
10	Steering stem	1	




Order	Job name/Part name	Q'ty	Remarks
11	Oil seal	1	Refer to "REMOVING THE BEARING RETAINER" and "INSTALLING THE BEARING RETAINER" in CHAPTER 8. (Manual No.: 5TE2-AE1)
12	Bearing retainer	1	
13	Bearing	1	
14	Oil seal	1	
			For installation, reverse the removal procedure.


FRONT ARMS AND FRONT SHOCK ABSORBERS



Order	Job name/Part name	Q'ty	Remarks
	Removing the front arms and front shock absorbers		Remove the parts in the order below.
	Engine skid plate		Refer to "SEAT, CARRIERS, FENDERS AND FUEL TANK".
	Front fender		
	Front wheel/brake disc		
			Refer to "FRONT AND REAR WHEELS" in CHAPTER 8. (Manual No.: 5TE2-AE1)
1	Air duct	1	
2	Brake disc guard	1	
3	Protector	1	




Order	Job name/Part name	Q'ty	Remarks
4	Nut	1	Refer to "REMOVING THE FRONT ARMS" and "INSTALLING THE FRONT ARMS AND FRONT SHOCK ABSORBER" in CHAPTER 8. (Manual No.: 5TE2-AE1) For installation, reverse the removal procedure.
5	Nut	1	
6	Bolt/nut	2/2	
7	Front lower arm/bushing	1/2	
8	Bolt/nut	2/2	
9	Front shock absorber	1	
10	Bolt/nut	2/2	
11	Front upper arm/bushing	1/2	
12	Circlip	1	
13	Ball joint	1	





ELECTRICAL

ELECTRIC STARTING SYSTEM

STARTER MOTOR



Order	Job name/Part name	Q'ty	Remarks
	Removing the starter motor		Remove the parts in the order below.
1	Starter motor lead	1	
2	Starter motor/O-ring	1/1	
			For installation, reverse the removal procedure.
	Disassembling the starter motor		Remove the parts in the order below.
①	Bracket 1	1	Refer to "ASSEMBLING THE STARTER MOTOR".
②	Washer kit		
③	Bracket 2/spacer	1	
④	Shims		
⑤	Brush holder set	1	
⑥	Armature coil	1	
⑦	Yoke	1	
			For assembly, reverse the disassembly procedure.




ASSEMBLING THE STARTER MOTOR

1. Install:

- Brush holder set ①

NOTE:

Align the projection ① on the brush seat with the slot ② on the bracket.




2. Install:

- Yoke
- Brackets


NOTE:


Align the match marks ① on the yoke with the match marks ② on the brackets.



EB806000


SIGNAL SYSTEM CIRCUIT DIAGRAM





- ③ Main switch
- ④ Battery
- ⑤ Main fuse
- ⑧ CDI unit
- ⑪ Thermo unit
- ⑫ Reverse switch
- ⑬ Neutral switch
- ⑰ Oil temperature warning light
- ⑱ Four-wheel drive indicator light
- ⑲ Diode
- ⑳ Four-wheel drive fuse
- ㉒ Gear motor
- ㉕ Neutral indicator light
- ㉖ Reverse indicator light
- ㉘ Ignition fuse
- ㉚ Signaling system fuse
- ㉜ Horn switch
- ㉝ Horn
- ㉞ Engine stop switch
- ㉟ Start switch
- ㊱ Front brake light switch
- ㊲ Rear brake light switch
- ㊳ Tail/brake light
- ㊴ Rear brake switch

Ⓐ For Europe and Oceania



1.If the oil temperature warning light does not come on:

- Check that the light comes on when the start switch is pushed on.
- Check that the light comes on when the oil temperature is 145 °C (293 °F) or higher.


1.Bulb and bulb socket
Check the bulb and bulb socket for continuity.

CONTINUITY

NO CONTINUITY

Replace the bulb and/or bulb socket.

2.Voltage
• Connect the pocket tester (DC 20 V) to the bulb socket coupler (wire harness side).
Tester (+) lead → Red/Black terminal ①
Tester (-) lead → White/Blue terminal ②



• Turn the start switch to “” and the main switch to “ON”.
• Check the voltage (12 V).

MEETS SPECIFICATION

OUT OF SPECIFICATION

The wiring circuit from the main switch to the bulb socket connector is faulty, repair it.

3.Start switch
Refer to “CHECKING THE SWITCHES” in CHAPTER 9. (Manual No.: 5TE2-AE1)

CORRECT
*


INCORRECT

Replace the handlebar switch (left).



4. Diode

- Remove the diode from the coupler.
- Connect the pocket tester ($\Omega \times 1$) to the diode terminals as shown.
- Check the diode for continuity as follows.



NOTE: When you switch the tester's positive and negative probes, the readings in the left chart will be reversed.

Tester (+) lead → Blue/Black terminal ①	Continuity
Tester (-) lead → White/Blue terminal ②	
Tester (+) lead → White/Blue terminal ②	No continuity
Tester (-) lead → Blue/Black terminal ①	

INCORRECT



Replace the diode.



5. Thermo unit


- Remove the thermo unit from the crankcase.
- Connect the pocket tester ($\Omega \times 100$) to the thermo unit ①.
- Immerse the thermo unit in engine oil ②.
- Measure the resistance.

	Thermo unit resistance:
	150 °C (302 °F): 307 ~ 339 Ω 170 °C (338 °F): 209 ~ 231 Ω

⚠ WARNING

Handle the thermo unit with special care. Never subject it to a strong shock or allow it to be dropped. Should it be dropped, it must be replaced.


Thermo unit:
20 Nm (2.0 m • kg, 14 ft • lb)




BAD CONDITION



Replace the thermo unit.



Replace the CDI unit.



TROUBLESHOOTING

IF THE FAN MOTOR DOES NOT MOVE:

Procedure

Check:

- 1.Fuses (main, ignition)
- 2.Battery
- 3.Main switch
- 4.Fan motor
- 5.Circuit breaker (fan motor)
- 6.Fan motor relay
- 7.Thermo unit
- 8.Wiring connections (the entire cooling system)

NOTE:

- Remove the following part(s) before troubleshooting.
 - 1)Seat
 - 2)Front carrier
 - 3)Front fender
- Use the following special tool(s) for troubleshooting.



Pocket tester:
P/N. YU-03112-C, 90890-03112

EB802011

1.Fuses (main, ignition)
Refer to "CHECKING THE SWITCHES" in CHAPTER 9. (Manual No.: 5TE2-AE1)

CONTINUITY

NO CONTINUITY

Replace the fuse.

EB802012

2.Battery
• Check the battery condition.
Refer to "CHECKING THE BATTERY" in CHAPTER 3. (Manual No.: 5TE2-AE1)
Open-circuit voltage:
12.8 V or more at 20 °C (68 °F)

CORRECT

INCORRECT


- Clean the battery terminals.
- Recharge or replace the battery.

3.Main switch
Refer to "CHECKING THE SWITCHES" in CHAPTER 9. (Manual No.: 5TE2-AE1)

CORRECT
*

INCORRECT

Replace the main switch.



4. Fan motor

- Disconnect the fan motor coupler.
- Connect the battery (12 V) as shown.

Battery (+) lead → Red terminal ①
Battery (-) lead → Black terminal ②

- Check the operation of the fan motor.

DOES NOT TURN

Replace the fan motor.




5. Circuit breaker (fan motor)


- Remove the circuit breaker from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) to the circuit breaker.

Circuit breaker resistance:
Zero Ω at 20 °C (68 °F)

OUT OF SPECIFICATION

Replace the circuit breaker.






6. Fan motor relay

- Remove the fan motor relay from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) and the battery (12 V) to the fan motor relay terminals.

Tester (+) lead → Red/Black terminal ①
Tester (-) lead → Blue terminal ②

Battery (+) terminal → Red/White terminal ③
Battery (-) terminal → White/Yellow terminal ④

- Check the fan motor relay for continuity.



NO CONTINUITY

Replace the fan motor relay.



7. Thermo unit

- Remove the thermo unit from the crankcase.
- Connect the pocket tester ($\Omega \times 100$) to the thermo unit ①.
- Immerse the thermo unit in engine oil ②.
- Measure the resistance.




Thermo unit resistance:
 150 °C (302 °F): 307 ~ 339 Ω
 170 °C (338 °F): 209 ~ 231 Ω

⚠ WARNING

Handle the thermo unit with special care. Never subject it to a strong shock or allow it to be dropped. Should it be dropped, it must be replaced.





Thermo unit:
 20 Nm (2.0 m • kg, 14 ft • lb)



BAD CONDITION

Replace the thermo unit.





EB803028

8. Wiring connections

- Check the connections of the entire starting system.
Refer to "CIRCUIT DIAGRAM".



CORRECT

Replace the CDI unit.

POOR CONNECTION



Properly connect the cooling system.

TROUBLESHOOTING

NOTE:

The following troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to troubleshooting. Refer to the relative procedure in this manual for checking, adjusting and replacing of parts.

FAULTY GEAR SHIFTING

HARD SHIFTING

Refer to “CLUTCH SLIPPING” in CHAPTER 10 (Manual No.: 5TE2-AE1).

SHIFT LEVER DOES NOT MOVE

Shift shaft

- Groove jammed with impurities
- Bent shift shaft

Shift fork

- Seized shift fork
- Bent shift fork guide bar

Transmission

- Seized transmission gear
- Jammed impurities
- Incorrectly assembled transmission

Shift guide

- Broken shift guide

JUMPS OUT OF GEAR

Shift shaft

- Improperly adjusted shift lever position
- Worn shift shaft lever
- Improperly returned stopper lever
- Improper thrust play
- Worn shift shaft groove

Shift fork

- Worn shift fork

Transmission

- Worn gear dog

OVERHEATING

OVERHEATING

Ignition system

- Improper spark plug gap
- Improper spark plug heat range
- Faulty CDI unit

Fuel system

- Improper carburetor main jet (improper setting)
- Improper fuel level
- Clogged air filter element

Compression system

- Heavy carbon build-up

Engine oil

- Improper oil level
- Improper oil viscosity
- Inferior oil quality

Brake

- Brake drag

Oil cooling system

- Faulty thermo unit
- Faulty CDI unit
- Faulty fan motor relay
- Faulty fan motor circuit breaker
- Clogged or damaged oil cooler
- Inoperative fan motor

EBS00549

FAULTY BRAKE

POOR BRAKING EFFECT

Front disc brake

- Worn brake pads
- Worn disc
- Air in brake fluid
- Leaking brake fluid
- Faulty master cylinder kit cup
- Faulty caliper kit seal
- Loose union bolt
- Broken brake hose and pipe
- Oily or greasy disc/brake pads
- Improper brake fluid level


Rear drum brake

- Worn brake shoe lining
- Worn brake drum
- Oily or greasy brake shoe lining
- Oily or greasy brake drum
- Improperly adjusted brake lever free play
- Improper brake cam lever position
- Fatigued/damaged return spring



YAMAHA MOTOR CO., LTD.
2500 SHINGAI IWATA SHIZUOKA JAPAN

YFM35FAS/YFM350FAS WIRING DIAGRAM



- ① A.C. magneto
 - ② Rectifier/regulator
 - ③ Main switch
 - ④ Battery
 - ⑤ Main fuse
 - ⑥ Starter relay
 - ⑦ Starter motor
 - ⑧ CDI unit
 - ⑨ Ignition coil
 - ⑩ Spark plug
 - ⑪ Thermo unit
 - ⑫ Reverse switch
 - ⑬ Neutral switch
 - ⑭ Circuit breaker (fan motor)
 - ⑮ Fan motor relay
 - ⑯ Fan motor
 - ⑰ Oil temperature warning light
 - ⑱ Four-wheel drive indicator light
 - ⑲ Diode
 - ⑳ Four-wheel drive fuse
 - ㉑ On-command four-wheel drive switch
 - ㉒ Gear motor
 - ㉓ Auxiliary DC jack fuse
 - ㉔ Auxiliary DC jack
 - ㉕ Neutral indicator light
 - ㉖ Reverse indicator light
 - ㉗ Speedometer light
 - ㉘ Ignition fuse
 - ㉙ Headlight fuse
 - ㉚ Signaling system fuse
 - ㉛ Hour meter
 - ㉜ Horn switch
 - ㉝ Horn
 - ㉞ Handlebar switch (left)
 - ㉟ Light switch
 - ㊱ Engine stop switch
 - ㊲ Start switch
 - ㊳ Headlight
 - ㊴ Front brake light switch
 - ㊵ Rear brake light switch
 - ㊶ Tail/brake light
 - ㊷ Rear brake switch
 - ㊸ Carburetor heater fuse
 - ㊹ Carburetor heater
 - ㊺ Thermo switch
- A For Europe and Oceania
B Optional
C Optional (for Europe and Oceania)

COLOR CODE

B..... Black	P Pink	B/W Black/White	G/Y Green/Yellow	R/W Red/White
Br Brown	R Red	Br/L Brown/Blue	L/B Blue/Black	R/Y Red/Yellow
Dg Dark green	Sb Sky blue	Br/R Brown/Red	L/G Blue/Green	W/G White/Green
G Green	W White	Br/W Brown/White	L/R Blue/Red	W/L White/Blue
L Blue	Y Yellow	G/L Green/Blue	L/W Blue/White	W/R White/Red
O Orange	B/Y Black/Yellow	G/W Green/White	R/B Red/Black	W/Y White/Yellow